


KPN Series

Features

- Super high-speed sampling cycle
(10 times faster compared to existing models)
: 50 ms sampling cycle and $\pm 0.3\%$ display accuracy
- Improved visibility with wide display and high luminance LED
- Easy check control output MV with Bar graph
- High performance control with heating/cooling control and automatic/manual control modes
- PC parameter setting
(via USB and RS485 communication)
: Integrated device management program (DAQMaster) supported
- ✕ Communication converter, sold separately: SCM-US (USB to Serial converter), SCM-38I (RS232C to RS485 converter), SCM-US48I (USB to RS485 converter)
- Selectable SSR output or current output
- Heater disconnection alarm (CT input) function
✕ CT, sold separately: CSTC-E80LN, CSTC-E200LN
- Multi-SV (up to 4) setting (selectable by digital input terminal)
- Space saving with compact design: downsized by 38% depth-based (panel rear length: 60 mm)
- Terminal cover, sold separately: R□A-COVER
- Multi-input/Multi-range



 Please read "Caution for your safety" in operation manual before using this unit.

Manual

- For more information and instructions, refer to the user manual and the user manual for communication. Visit our web site (www.konics.com) to download the manuals.
- The user manual includes product specifications, functions, and operations.
- The user manual for communication includes information about Modbus RTU protocol, and Modbus mapping table.


Software

- DAQMaster is the integrated device management program to set parameters and manage monitoring data and use user parameter group, parameter masking function only for KPN Series.
- Visit our web site (www.konics.com) to download this software and the user manuals.

< Computer specifications for using software >

Item	Recommended specifications
System	Over IBM PC compatible computer with Pentium III
Operating system	Microsoft Windows 98/NT/XP/Vista/Window 7
Memory	Over 256MB
Hard disk	Over 1GB (available space)
Resolution	Over 1024×768
Communication port	RS-232 serial port (9-pin), USB port

< DAQMaster screenshot >



High performance & accuracy process controller

Ordering information


KPN5	5	0	0	0	0	0
Power supply						
0 100-240 VAC 50/60 Hz						
Option input/output						
0 None						
3 Transmission output + Remote SV						
Option communication output						
0 None						
2 RS485						
Control output*1						
1 output type		0	Relay, Current, SSR drive voltage selection output			
		1	OUT1: Current, SSR drive voltage selection output OUT2: Current, SSR drive voltage selection output			
		3	OUT1: Current, SSR drive voltage selection output OUT2: Relay output			
		7	OUT1: Relay output OUT2: Current, SSR drive voltage selection output			
		9	OUT1: Relay output OUT2: Relay output			
2 output type						
The number of control outputs						
0 1 output type (Heating or Cooling type)						
1 2 output type (Heating&Cooling type)						
Size						
3 DIN W48×H96 mm						
5 DIN W96×H96 mm						
Item						
KPN5 Temperature / Process Controller						

- ※ 1: The 1 output type is heating or cooling output type and the 2 output type is heating & cooling output type.
 The 1 output type is able to use only one output among relay, current, SSR drive voltage outputs.
 OUT1 of the 2 output type is fixed as heating output and OUT2 of the 2 output type is fixed as cooling output.
 If you select the SSR drive voltage or current output model, you can select the appropriate control output.

A. Recorder
B. Indicator
C. Converter
D. Controller
E. Thyristor unit
F. Temp. sensor
G. Pressure transmitter
H. Temp. transmitter
I. Thermometer
J. Pressure gauge
K. Accessories


Connections

© KPN5□00



- ※ 1: Set relay output [RLY], current [CUR], or SSR drive voltage output [SSV] at OUT1 control output [OUT1] in parameter 3 group.
 ※ Standard model has shaded terminals only.
 [] is option specification.

© KPN5□1□



※ 2: OUT1, OUT2

Model	OUT1 control output	OUT2 control output
KPN5□11	Current, SSR drive voltage selection output	Current, SSR drive voltage selection output
KPN5□13	Current, SSR drive voltage selection output	Relay output
KPN5□17	Relay output	Current, SSR drive voltage selection output
KPN5□19	Relay output	Relay output


KPN

KCR-311


KPN Series

Dimensions

◎ KPN53□□




◎ KPN55□□




◎ Terminal cover (sold separately)

● RHA-COVER (48×96 mm size)




● RLA-COVER (96×96 mm size)



◎ Current transformer (CT, sold separately)



● CSTC-E80LN

- Current measuring range: 100 mA-80 A(Rb=10 Ω)
- Wire wound resistance: 31 Ω±10%
- Current ratio: 1000:1
- Accuracy: 2.0 grade(5 A to 8 A)



● CSTC-E200LN

- Current measuring range: 100 mA-200 A(Rb=10Ω)
- Wire wound resistance: 20 Ω±10%
- Current ratio: 1000:1
- Accuracy: 2.0 grade(5 A to 200 A)



(unit:mm)

Model	A	B	C	D	E	F
CSTC-E80N	Φ23.3	Φ7	26.5	7	3.8	10.5
CSTC-E200N	Φ37.1	Φ13	40.8	10	4.5	13.5

※ When using a CT, do not apply primary current when opening CT output. Or high voltage occurs at CT output.

High performance & accuracy process controller

Specifications

Series	KPN53□□	KPN55□□
Power supply	100-240 VAC 50/60 Hz	
Allowable voltage range	90 to 110% of rated voltage	
Power consumption	Max. 15 VA	
Display method	7Segment(red, green), control Bar graph: red, green	
Character size	PV(W×H)	7.0×14.6 mm
	SV(W×H)	6.0×12.0 mm
Input type	RTD	JPt100Ω, DPt100Ω, DPt50Ω, Cu100Ω, Cu50Ω, Nickel120Ω(6 types)
	TC	K, J, E, T, L, N, U, R, S, B, C, G, PLII(13 types)
	Analog	· Voltage: 0-100 mV, 0-5 V, 1-5 V, 0-10 V(4 types) · Current: 0-20 mA, 4-20 mA(2 types)
Display accuracy	RTD	· At room temperature (23±5 °C): (PV ±0.3% or ±1 °C, select the higher one) ±1digit ※1
	TC	· Out of room temperature range: (PV ±0.5% or ±2 °C, select the higher one) ±1digit
	Analog	At room temperature (23±5 °C): ±0.3% F.S.±1digit, Out of room temperature range: ±0.5% F.S.±1digit
	CT input	±5% F.S.±1digit
Control output	Relay	OUT1, OUT2 : 250 VAC 5 A 1 a
	SSR	Max. 11 VDC±2 V 20 mA
	Current	0-20 mA or 4-20 mA selectable (max. load 500 Ω)
Alarm output	Relay	AL1, AL2, AL3 Relay contact capacity 250 VAC 3 A 1 a
Option output	Transmission	4-20 mA (Load max. 600 Ω, output accuracy: ±0.3% F.S.±1digit)
	Communication	RS485 communication output (Modbus RTU method)
Option input	CT	0.0-50.0 A(primary heater current value measuring range) ※CT ratio is 1000:1
	Remote SV	1-5 VDC or 4-20 mA(current input: using external resistance 250 Ω)
	Digital input	· Contact input: Max. 2 kΩ in ON, Min. 90 kΩ in ON · Non-contact input: Residual voltage max. 1.0 V in ON, leakage current max. 0.1 mA in OFF
Control type	Heating, Cooling	ON/OFF control, P, PI, PD, PID control
	Heating&Cooling	
Hysteresis	· Thermocouple/RTD: 1 to 100 °C/°F(0.1 to 100.0 °C/°F) variable · Analog: 1 to 100 digit	
Proportional band (P)	0.1 to 999.9 °C(0.1 to 999.9%)	
Integral time(I)	0 to 9999 sec.	
Derivative time (D)	0 to 9999 sec.	
Control period(T)	0.1 to 120.0 sec.(relay output, SSR drive voltage output only)	
Manual reset value	0.0 to 100.0%	
Sampling period	50 ms	
Dielectric strength	2000 VAC 50/60 Hz for 1 min. (between input terminal and power source terminal)	
Vibration	0.75 mm amplitude at frequency of 5 to 55 Hz (for 1 min.) in each X, Y, Z direction for 2 hours	
Relay life cycle	Mechanical	Over 10,000,000 times
	Electrical	Over 100,000 times (250 VAC 3 A resistance load)
Insulation resistance	Over 100 MΩ at 500 VDC megger)	
Noise resistance	Square shaped noise by noise simulator (pulse width 1μs) ±2 kV R-phase, S-phase	
Memory retention	Approx. 10 years (when using non-volatile semiconductor memory type)	
Environment	Ambient temperature	-10 to 50 °C, storage: -20 to 60 °C
	Ambient humidity	35 to 85%RH, storage: 35 to 85%RH
Protection	IP65(front part)	
Insulation type	Double insulation or reinforced insulation(mark: □), dielectric strength between the measuring input part and the power part: 1kV)	
Unit weight	Approx. 160 g	Approx. 220 g

※1. ◎ At room temperature (23 °C±5 °C)

- TC K, J, T, N, E type, below -100 °C / L, U, PLII, RTD Cu50, DPt50: (PV ±0.3% or ±2 °C, select the higher one) ±1digit
- TC C, G and R, S type, below 200 °C: (PV ±0.3% or ±3 °C, select the higher one) ±1digit
- TC B type, below 400 °C, there is no accuracy standards.

◎ Out of room temperature range

- RTD Cu50, DPt50: (PV 0.5% or ±3 °C, select the higher one) ±1digit
- RTD R, S, B, C, G: (PV ±0.5% or ±10 °C, select the higher one) ±1digit
- Other sensors: Below -100 °C, within ±5 °C

※ Environment resistance is rated at no freezing or condensation.

A. Recorder

B. Indicator

C. Converter

D. Controller

E. Thyristor unit

F. Temp. sensor

G. Pressure transmitter

H. Temp. transmitter

I. Thermometer

J. Pressure gauge

K. Accessories

KPN

KCR-311

KPN Series

Input type and range



Input type		Dot	Parameter	Temperature range (°C)	Temperature range (°F)
Thermocouple	K(CA)	1	EC.E1	-200 to 1350	-328 to 2463
		0.1	EC.E2	-199.9 to 999.9	-199.9 to 999.9
	J(IC)	1	EC.J1	-200 to 800	-328 to 1472
		0.1	EC.J2	-199.9 to 800.0	-199.9 to 999.9
	E(CR)	1	EC.E1	-200 to 800	-328 to 1472
		0.1	EC.E2	-199.9 to 800.0	-199.9 to 999.9
	T(CC)	1	EC.T1	-200 to 400	-328 to 752
		0.1	EC.T2	-199.9 to 400.0	-199.9 to 752.0
	B(PR)	1	EC-b	0 to 1800	32 to 3272
	R(PR)	1	EC-r	0 to 1750	32 to 3182
	S(PR)	1	EC-S	0 to 1750	32 to 3182
	N(NN)	1	EC-n	-200 to 1300	-328 to 2372
	C(TT)*1	1	EC-C	0 to 2300	32 to 4172
	G(TT)*2	1	EC-G	0 to 2300	32 to 4172
L(IC)	1	EC.L1	-200 to 900	-328 to 1652	
	0.1	EC.L2	-199.9 to 900.0	-199.9 to 999.9	
U(CC)	1	EC.U1	-200 to 400	-328 to 752	
	0.1	EC.U2	-199.9 to 400.0	-199.9 to 752.0	
RTD	Platinel II	1	EC-P	0 to 1390	32 to 2534
	Cu50Ω	0.1	CU.50	-199.9 to 200.0	-199.9 to 392.0
	Cu100Ω	0.1	CU.10	-199.9 to 200.0	-199.9 to 392.0
	JPt100Ω	1	JPt.1	-200 to 650	-328 to 1202
		0.1	JPt.2	-199.9 to 650.0	-199.9 to 999.9
	DPt50Ω	0.1	dPt.5	-199.9 to 650.0	-199.9 to 999.9
	DPt100Ω	1	dPt.1	-200 to 650	-328 to 1202
		0.1	dPt.2	-199.9 to 650.0	-199.9 to 999.9
Nickel120Ω	1	n1.12	-80 to 200	-112 to 392	
Analog	0-10 V		A-u1	-1999 to 9999 (Display range is variable according to decimal point position.)	
	0-5 V		A-u2		
	1-5 V		A-u3		
	0-100 mV		A.nu1		
	0-20 mA		A.nA1		
	4-20 mA		A.nA2		

※ 1: C(TT) : Same as existing W5(TT) type sensor.

※ 2: G(TT) : Same as existing W(TT) type sensor.

High performance & accuracy process controller

Part descriptions



① Measured value(PV) display part

- RUN mode: Displays currently measured value (PV).
- Set mode: Displays the parameters.

② Set value (SV) display part

- RUN mode: Displays the set value (SV).
- Set mode: Displays the set value of the parameter.

③ Unit(°C/°F/%) indicator: Displays the unit set at display unit [dL n E] in parameter 3 group.

④ Manual control indicator : Turns ON during manual controlling.

⑤ Remote SV control indicator : Turns ON during remote SV controlling.

⑥ Control output (OUT1, OUT2) indicator: Turns ON when the control output is ON.

※ using current output, in case that for manual control MV is 0.0%, the control output indicator turns OFF but the other cases it turns ON always. In case that for auto control MV is over 3.0%, it turns ON and the MV is below 2.0%, it turns OFF.

⑦ Auto tuning indicator: Flashes by 1 sec. when executing auto tuning.

⑧ Alarm output (AL1, AL2, AL3) indicator: Turns ON when the alarm output is ON.

⑨ Multi SV indicator: The SV 1 to 3 indicator turns ON when using multi SV function. .

⑩ Bar graph for control output: Displays control output MV as bar graph.

KPN5□0□ as 1 output type has one bar graph (OUT1), and the KPN5□1□ as 2 output type has two bar graphs (OUT1, OUT2).

⑪ **A/M** key: Used when switching auto control to manual control.

⑫ **MODE** key: Used when entering parameter setting group, returning to RUN mode, moving parameter, saving the set value.

⑬ **←**, **✓**, **↑** key: Used when entering the set value changing mode and moving or changing up/down digit.

⑭ Digital input key : When pressing **✓** + **↑** keys for 3 sec. at the same time, it operates the function (RUN/STOP, alarm clear, auto-tuning) set at digital input key [d l - E] in parameter 5 group.

⑮ PC loader port: It is the PC loader port for serial communication to set and monitor parameters by PC. Use this port for connection SCM-US (USB to serial convertor).

※ Display part is different by options.

A. Recorder

B. Indicator

C. Converter

D. Controller

E. Thyristor unit

F. Temp. sensor

G. Pressure transmitter

H. Temp. transmitter

I. Thermometer

J. Pressure gauge

K. Accessories

KPN

KCR-311

SV settings


You can set the temperature to control with the **←**, **✓**, **↑** keys.

Set range is within SV low-limit value [L - 5 u] to SV high-limit value [H - 5 u].


※ Ex) In case of changing set temperature from 210°C to 250°C




Press any key among the **←**, **✓**, **↑** in RUN mode to enter into SV setting mode. Last digit (100 digit) on SV display part flashes.



Press the **←** key to move digit. (10⁰→10¹→10²→10³→10⁰)




Press the **✓** or **↑** key to raise or lower the setting value. (1 → 5)



Press the **MODE** key to save the setting value. If there is no additional key operations in 3 sec., the changed SV is automatically saved.

Parameter groups



- ※1: PASS parameter is displayed only when password is set.
It is not displayed when purchasing the unit because the default password is set to 0000.
If the password is not valid, the screen is changed to the password code screen.
Press any key among the \leftarrow , \rightarrow , \uparrow , \downarrow key to return to password entering window. Press the **MODE** key to return to RUN mode.
If you forget the password, contact our service center after checking the password code.
- ※2: It is displayed when setting user parameter group in the integrated device management program (DAQMaster).

- ※ Press the **MODE** key over 2 sec. in RUN mode to enter.
- ※ Press the **MODE** key for 1.5 sec. while in setting mode to move to other parameter group.
- ※ Press the **MODE** key over 3 sec. while in setting mode to return to RUN mode.
- ※ Press the **MODE** key at the lowest level of parameter to move parameter group screen. Press the \rightarrow , \leftarrow keys to move other parameter groups.
- ※ If there is no additional key operation within 30 sec. after entering into setting mode, it will be automatically returned to RUN mode and previous setting value will be remained.
- ※ The shaded parameters are displayed in common. The others may not be displayed by the specifications of the product, other parameter's setting, or parameter mask setting.

High performance & accuracy process controller

A. Recorder

B. Indicator

C. Converter

D. Controller

E. Thyristor unit

F. Temp. sensor

G. Pressure transmitter

H. Temp. transmitter


I. Thermometer

J. Pressure gauge

K. Accessories


KPN

KCR-311



KPN Series

Parameter 1 group




High performance & accuracy process controller

Parameter 2 group


- ※1. **S** : Press any key among the \leftarrow , \rightarrow , \uparrow .
- ※ After entering setting group, press the **MODE** key for 3 sec., it returns to RUN mode.
- ※ After entering setting group, press the **MODE** key for 1.5 sec., it returns to the related group name.
- ※ \square : This parameter may or may not appear, depending on the other parameter set.
- ※ Press the **MODE** key after checking/changing SV in each parameter to save SV.

A. Recorder
B. Indicator
C. Converter
D. Controller
E. Thyristor unit
F. Temp. sensor
G. Pressure transmitter
H. Temp. transmitter
I. Thermometer
J. Pressure gauge
K. Accessories

KPN
KCR-311




KPN Series




Parameter 3 group

- ※1. [S]: Press any key among the [←], [↓], [↑].
- ※ After entering setting group, press the [MODE] key for 3 sec., it returns to RUN mode.
- ※ After entering setting group, press the [MODE] key for 1.5 sec., it returns to the related group name.
- ※ []: This parameter may or may not appear, depending on the other parameter set.
- ※ Press the [MODE] key after checking/changing SV in each parameter to save SV.



High performance & accuracy process controller



A. Recorder
B. Indicator
C. Converter
D. Controller
E. Thyristor unit
F. Temp. sensor
G. Pressure transmitter
H. Temp. transmitter
I. Thermometer
J. Pressure gauge
K. Accessories

KPN
KCR-311

KPN Series

Parameter 4 group


※1. **S** : Press any key among the \leftarrow , \rightarrow , \uparrow , \downarrow .

※ After entering setting group, press the **MODE** key for 3 sec., it returns to RUN mode.


※ After entering setting group, press the **MODE** key for 1.5 sec., it returns to the related group name.

※ \square : This parameter may or may not appear, depending on the other parameter set.

※ Press the **MODE** key after checking/changing SV in each parameter to save SV.



High performance & accuracy process controller



A. Recorder
B. Indicator
C. Converter
D. Controller
E. Thyristor unit
F. Temp. sensor
G. Pressure transmitter
H. Temp. transmitter
I. Thermometer
J. Pressure gauge
K. Accessories

KPN
KCR-311

KPN Series

Parameter 5 group


※1. **S** : Press any key among the \leftarrow , \rightarrow , \uparrow , \downarrow .

※ After entering setting group, press the **MODE** key for 3 sec., it returns to RUN mode.


※ After entering setting group, press the **MODE** key for 1.5 sec., it returns to the related group name.

※ \dots : This parameter may or may not appear, depending on the other parameter set.

※ Press the **MODE** key after checking/changing SV in each parameter to save SV.



High performance & accuracy process controller



A. Recorder
B. Indicator
C. Converter
D. Controller
E. Thyristor unit
F. Temp. sensor
G. Pressure transmitter
H. Temp. transmitter
I. Thermometer
J. Pressure gauge
K. Accessories

KPN
KCR-311

Factory default

■ SV setting [S_v]

Parameter	Default
S _v	0

■ Password input parameter

Parameter	Default
PASS	0001

■ Parameter 1 group [PAr 1]

Parameter	Default	Parameter	Default	Parameter	Default	Parameter	Default
r-S	rUn	AL 1L	1550	AL 3L	0000	S _v -2	0000
S _v -n	S _v -0	AL 1H	1550	AL 3H	0000	S _v -3	0000
Ct-A	00	AL 2L	1550	S _v -0	0000		
AL 1L	1550	AL 2H	1550	S _v -1	0000		

■ Parameter 2 group [PAr 2]

Parameter	Default	Parameter	Default	Parameter	Default	Parameter	Default
AE	oFF	H-d	0000	HoSE	000	rAñU	000
H-P	0 100	C-d	0000	CHYS	002	rAñd	000
C-P	0 100	db	0000	CoSE	000	rUnt	ñi n
H-1	0000	rESE	0500	L-ñu	-1000		
C-1	0000	HHYS	002	H-ñu	1000		

■ Parameter 3 group [PAr 3]

Parameter	Default	Parameter	Default	Parameter	Default	Parameter	Default
ln-t	ECRAH	H-SC	1000	o-Ft	HEAE		55r
Unit	°C	dUnt	°rø		H-C	o lñA	4-20
L-rG	0000	ln-b	0000	C-ñd	Pl d	oUt2	55r
H-rG	1000	ñAUF	000.1		PP	o2ñA	4-20
dot	00	L-S _v	-200	AEt	tUn 1	H-t	0200 (Relay)
L-SC	0000	H-S _v	1350	oUt 1	rLY	C-t	0000 (SSR drive)

■ Parameter 4 group [PAr 4]

Parameter	Default	Parameter	Default	Parameter	Default	Parameter	Default	Parameter	Default
AL-1	dUCC	AL-2]]dU	AL-3	LbA	LbAE	0000	bPS	96
AL 1t	AL-A	AL 2t	AL-A	AL 3t	AL-A	LbAb	002	Prty	nonE
ALHY	001	A2HY	001	A3HY	001	Aoñ	Pu	StP	2
A 1n	no	A2n	no	A3n	no	FSL	-200	rSYt	20
A 1on	0000	A2on	0000	A3on	0000	F5H	1350	CoñY	EnA
A 1oF	0000	A2oF	0000	A3oF	0000	AdrS	01		

■ Parameter 5 group [PAr 5]

Parameter	Default	Parameter	Default	Parameter	Default	Parameter	Default
ñt.S _v	1	rSPn	1000	Stñu	0000	LCP3	oFF
d1-t	StoP	bAr	oUt 1	StAL	Cont	LCP4	oFF
d1-1	oFF		ALL	USEr	Stnd	LCP5	oFF
d1-2	oFF	1 tñu	AUto	LCS _v	oFF	PYd	0000
rES _v	oFF	Prñu	0000	LCP 1	oFF		
r 1nb	0000	Erñu	0000	LCP2	oFF		

※ Shaded parameters are factory defaults for the heating & cooling model.

High performance & accuracy process controller

Functions

Alarm

Mode	Name	Operation	Description
OFF	—	—	No alarm output
$d_u \llcorner$	Deviation high-limit alarm	<p>High deviation : Set as 10°C High deviation : Set as -10°C</p>	If deviation between PV and SV as high-limit is higher than set value of deviation temperature, the alarm output will be ON.
$\llcorner d_u$	Deviation low-limit alarm	<p>Low deviation : Set as 10°C Low deviation : Set as -10°C</p>	If deviation between PV and SV as low-limit is higher than set value of deviation temperature, the alarm output will be ON.
$\llcorner d_u \llcorner$	Deviation high/low-limit alarm	<p>Low deviation : Set as 10°C , High deviation : Set as 20°C</p>	If deviation between PV and SV as high/low-limit is higher than set value of deviation temperature, the alarm output will be ON.
$\llcorner d_u$	Deviation high/low-limit reserve alarm	<p>Low deviation : Set as 10°C , High deviation : Set as 20°C</p>	If deviation between PV and SV as high/low-limit is higher than set value of deviation temperature, the alarm output will be OFF.
$P_u \llcorner$	Absolute value high limit alarm	<p>Absolute value alarm : Set as 90°C Absolute value alarm : Set as 110°C</p>	If PV is higher than the absolute value, the output will be ON.
$\llcorner P_u$	Absolute value low limit alarm	<p>Absolute value alarm : Set as 90°C Absolute value alarm : Set as 110°C</p>	If PV is lower than the absolute value, the output will be ON.
$L b A$	Loop break alarm	—	It will be ON when it detects loop break.
$S b A$	Sensor break alarm	—	It will be ON when it detects sensor disconnection.
$H b A$	Heater break alarm	—	It will be ON when CT detects heater break.

※ H : alarm output □ hysteresis [R□,HY]

Alarm output

Mode	Name	Description
$R L - A$	Standard alarm	If it is an alarm condition, alarm output is ON. If it is a clear alarm condition, alarm output is OFF.
$R L - b$	Alarm latch	If it is an alarm condition, alarm output is ON and maintains ON status.
$R L - \llcorner$	Standby sequence 1	First alarm condition is ignored and from second alarm condition, standard alarm operates. When power is supplied and it is an alarm condition, this first alarm condition is ignored and from the second alarm condition, standard alarm operates.
$R L - d$	Alarm latch and standby sequence 1	If it is an alarm condition, it operates both alarm latch and standby sequence. When power is supplied and it is an alarm condition, this first alarm condition is ignored and from the second alarm condition, alarm latch operates.
$R L - E$	Standby sequence 2	First alarm condition is ignored and from second alarm condition, standard alarm operates. When re-applied standby sequence and if it is alarm condition, alarm output does not turn ON. After clearing alarm condition, standard alarm operates.
$R L - F$	Alarm latch and standby sequence 2	Basic operation is same as alarm latch and standby sequence 1. If it operates not only by power ON/OFF, but also alarm setting value, or alarm option changing. When re-applied standby sequence and if it is alarm condition, alarm output does not turn ON. After clearing alarm condition, alarm latch operates.

※ Condition of re-applied standby sequence for standby sequence 1, alarm latch and standby sequence 1: Power ON

Condition of re-applied standby sequence for standby sequence 2, alarm latch and standby sequence 2: Power ON, changing set temperature, alarm temperature[RL 1, RL 2] or alarm operation [RL - 1, RL - 2] , switching STOP mode to RUN mode.

A. Recorder

B. Indicator

C. Converter

D. Controller

E. Thyristor unit

F. Temp. sensor

G. Pressure transmitter

H. Temp. transmitter

I. Thermometer

J. Pressure gauge


K. Accessories

KPN

KCR-311

■ Control output mode [α -Ft]

- Control output modes for general temperature control include heating, cooling, and heating/cooling.
- Heating control (reverse operation) and cooling control (normal operation) are mutually opposing operations with inverse outputs.
- The PID time constant varies based on the controlled objects during PID control.



Group	Parameter	Set range	Default	Unit
PRr3	α -Ft	Standard model HEAt/CooL	HEAt	—
		Heating & Cooling mode HEAt/CooL/H-C	H-C	—

■ Heating control [HEAt]

The output will be provided in order to supply power to the load (heater) if PV(present temperature) falls below SV(set temperature).

■ Cooling control [CooL]


The output will be provided in order to supply power to the load (cooler) if PV(present temperature) rises above SV(set temperature)

■ Heating/Cooling control [H-C]

Heating and Cooling with a single temperature controller when it is difficult to control subject temperature with only heating or cooling.

Heating and cooling control mode controls the object using different PID time constants for each heating and cooling.

It is also possible to set heating and cooling control in both PID control or ON/OFF control mode. Heating/cooling output can be selected among Relay output, SSR output and current output depending on model types chosen according to your application environment. (Note that only standard SSR control is available for SSR output in OUT2.)



※For heating and cooling control, OUT1 control output is dedicated to heating control and OUT2 control output to cooling control.

■ Auto-tuning [Rt]

In PID control, auto-tuning processes the control subject's thermal characteristics and thermal response rate, and then determines the necessary PID time constant. Application of the PID time constant realizes fast response and high precision temperature control.

- Auto-tuning automatically stores PID time constants upon termination. These PID time constants can then be modified by the user to suit their usage environment.
- When auto-tuning is in progress, the AT lamp located on the front of the controller flashes in 1-second intervals. When auto-tuning finishes, the AT lamp automatically goes off and the auto-tuning parameter will return to OFF.

SV	Description
α FF	Auto-tuning stops
α n	Auto-tuning starts

Group	Parameter	Set range	Default	Unit
PRr2	Rt	α FF/ α n	α FF	—

※Manual interruption or a sensor disconnection error when auto-tuning is in progress restores the PID time constant to the value used prior to the auto-tuning session.

※Auto-tuning continues to run even if the temperature reading exceeds or falls below the input range.

※When auto-tuning is in progress, parameters can only be referenced and not altered.

※Auto-tuning is not available in manual control. (Manual Control).

■ Control output(OUT1/OUT2) selection [α Ut 1 / α Ut 2]


- The 1 output type (OUT1) model supports relay, current, SSR drive voltage output.
- The 2 output type (OUT1, OUT2) model supports relay fixed or current, SSR drive voltage output.

■ Parameter mask

This function is able to hide unnecessary parameters to user environment or less frequently used parameters in parameter setting group. You can set this in the integrated device management program (DAQMaster).

Though masked parameters are not displayed in parameter setting group, the parameter setting values are applied. For more information, refer to the DAQMaster user manual. Visit our website (www.konics.com) to download the DAQMaster program and the user manual.

<Before applying mask>



<After applying mask>



The above is masking auto tuning [Rt], cooling proportional band [C-P], cooling integral time [C-I], cooling derivative time [C-d] parameters in parameter 2 group.


High performance & accuracy process controller

■ User parameter group [PARU]

This function is able to set the frequently used parameters to the user parameter group. You can quickly and easily set parameter settings.

User parameter group can have up to 30 parameters in the integrated device management program (DAQMaster). For more information, refer to the DAQMaster user manual.

Visit our website (www.konics.com) to download the DAQMaster program and the user manual.



The above is setting user parameter group in the DAQMaster with alarm output 1 low-limit value [AL IL], alarm output 1 high-limit value [AL IH], SV-0 set value [SV-0] parameters of parameter 1 group, heating hysteresis [HHYS], cooling hysteresis [CHYS] parameters of parameter 2 group,

input correction [I n - b], parameter of parameter 3 group, alarm output 1 hysteresis [A IH], alarm output 2 hysteresis [A2HY] parameters of parameter 4 group.

■ Bar graph

MV of control output (OUT1, OUT2) is displayed as the bar graph in real-time. According to bar graph setting [bAr] in parameter 5 group, it displays bar graph by control output or does not display it.

OUT1 (red LED)
 OUT2 (green LED)

One LED is 10% (total 10 LEDs: 100%). If control output MV is 0.1 to 10%, one LED turns ON. If MV is 90.1 to 100%, 10 LEDs turn ON.

The 1 output type (heating or cooling control) model has one OUT1 bar graph (red).

The 2 output type (heating & cooling control) model has two bar graphs; OUT1 bar graph (red), OUT2 bar graph (green). OUT1 is for heating MV and OUT2 is for cooling MV.

■ Remote SV setting

This function is to set SV by inputting analog (DC4-20 mA, 1-5 VDC) signal to no. 13 and 14 terminals. (Set that remote SV [rESV] is ON in parameter 5 group)

Input analog signal is changed to between SV low-limit value [L-SV] to SV high-limit value [H-SV].

※ When using remote SV, you cannot select SV setting by front keys and multi SV setting by digital input.

■ Parameter initialization

It initializes all parameters to factory default values. Press the front + + keys for 5 sec. at the same time and [ini] parameter is displayed. Select 'YES' to initialize all parameters.

If the password is set, you must enter the password. After initializing the parameters, the password parameter is also initialized.

※ ■ Refer to the KPN user manual for more functions.

Proper usage

■ Simple troubleshooting for process controller

- In case, the load (Heater, etc) is not operated, please check operation of the out indicator located in front panel of the unit. If the indicator does not operate, please check the parameter of all programmed mode. If the indicator is operating, please check the output (Relay, Driving voltage of SSR, DC4-20 mA current) after separating output line from the unit.

- When it displays "oPEr"

This is a warning that external sensor is cut off (open).

Please turn off power and check the state of sensor. If sensor is not cut off (open), disconnect sensor line from terminal block and +, - together. When you turn on power it can check room temperature.

If this unit cannot indicate room temperature, this unit itself is faulty. Please remove this unit from equipment and service or replace.

(When the input mode is thermocouple, it is available to indicate room temperature.)

- In case of indicating "Error" in display

This Error message is indicated in case of damaging inner chip program data by outer strong noise.

In this case, please send the unit to our after service center after removing the unit from system.

Noise protection is designed in this unit, but it does not stand up strong noise continuously.

If bigger noise than specified(Max. 2 kV) flows in the unit, it can be damaged.

■ Caution for using

- Use separated line from high voltage line or power line in order to avoid inductive noise.
- Install a power switch or circuit breaker in order to supply or cut off the power.
- The switch or circuit breaker should be installed nearby users for safety.
- This unit is designed for temperature controlling only. Do not apply this unit as a voltage meter or a current meter.
- In case of using RTD sensor, 3-wire type must be used. If you need to extend the line, use 3-wire with the same thickness as the line. It might cause temperature difference if the resistance of line is different.
- In case of making power line and input signal line closely, line filter for noise protection should be installed at power line and input signal line should be shielded.
- Be sure to avoid using the following unit nearby machinery making strong high frequency noise. (high frequency welder & sewing machine, high capacity SCR unit, etc.)
- Installation environment
 - ① It shall be used indoors.
 - ② Altitude max. 2,000 m
 - ③ Pollution degree 2
 - ④ Installation category II
- It may cause malfunction if above instructions are not followed.

A. Recorder
B. Indicator
C. Converter
D. Controller
E. Thyristor unit
F. Temp. sensor
G. Pressure transmitter
H. Temp. transmitter
I. Thermometer
J. Pressure gauge
K. Accessories

KPN
KCR-311